



P/N L0509FR Made in USA

2005-09 Front Splitter w/ GT Bumper Installation Instructions

Thank you for your purchase of SilverHorse Racing products. Please read all directions before beginning the installation. A factory shop manual should be available for reference during installation. If, after reading these and any accompanying directions, you feel that you may not be able to complete the installation safely and properly, please seek out professional installation by certified technicians. Please read and understand our product purchase agreement (included on yellow sheet) prior to starting installation. Vehicle should be off with key removed from ignition and in park with parking brake set prior to beginning installation.

Hardware Included:

12 – ¼ diameter –1” long stainless Bolts 24 – ¼ fender washers 12 – ¼ Nylock Nuts

Installation Instructions

The Legend splitter will use six existing holes in the factory bumper cover and six new holes predrilled in the new chin spoiler. These new holes will have to be drilled into the factory bumper cover.

- 1.) Raise the front of the vehicle to allow clearance for installation.
Note: Please take necessary precautions whenever jacking or working under a vehicle.
- 2.) Loosen the three bottom foreword screws in both the drivers and passenger side wheel wells. These screws attach the bumper cover to the inner well and give adjustability to the bumper cover.
- 3.) Next remove the four screws located on the bottom center of the bumper cover. These will be reinstalled with the new splitter.
- 4.) Next lift the chin spoiler in place on the car, aligning the raised center section of the spoiler in the factory bumper cover cutout. Use the four existing screws to temporarily hold the spoiler in place and also add a clamp to each side of the raised section to hold the center alignment.
- 5.) Using ¼ bolts, washers, and nuts install one each on drivers and passengers sides existing holes in bumper cover and corresponding holes in splitter. Only tighten until cover and splitter meet. Do not over tighten as further adjustment is required.
- 6.) Starting on the drivers side align the rear edge of the chin spoiler with the edge of the bumper cover and temporarily clamp in place. This can be done by holding the bumper cover edge and pulling the splitter in line with the bumper cover. Repeat this procedure on the passenger side of the vehicle.
- 7.) Check fit and make any minor adjustments necessary.
- 8.) With all adjustments complete drill new ¼ holes in bumper cover from predrilled ¼ holes in the splitter.
- 9.) Install the ¼ bolts, flat washers under both the bolt head and under the fiber nuts in the six new holes and secure. Use caution to not over tighten and crush either surface.
- 10.) Remove all clamps and tighten the three existing screws previously loosened in each wheel opening and the four existing screws located in the center bottom of the splitter.
- 11.) Your installation is now complete and ready to enjoy. Please remember to watch curbs and speed bumps.

If you have any questions, feel free to contact us at the number listed below or via email.

Tech Questions: (321)-722-2813.

Email us -

Tech@SilverHorseRacing.com

“If it’s not good enough for our cars, we won’t make it for yours.”



MEMBER